


Specific Wiring Method

- Wiring for 3H and 2C thermostat



S4-1 Default on, DH function off.
Turn switch off to activate DH function.

S4-2 Default on, W1 and W2 shorted for single stage Aux heat operation. Turn off to separate stages.